



INSTALLATION INSTRUCTIONS

Part Number 85-9001

This bracket fits: SEE CATALOG FOR CURRENT APPLICATIONS

High performance riding puts a lot of stress on the intake manifold. Use this bracket with K&N Adapter part number 85-9294 to stabilize the carburetors.

NOTE: Put Loctite on all fasteners and periodically check for cracks or looseness.

